

Computer Vision:

Week-2 (26-30 Jan) Theory Lectures

Dr. Irfan Ali

*Assistant Professor (AI, Multimedia Gaming & Cybersecurity
& Program Coordinator of Multimedia & Gaming Deptt*

Motion in an Image Sequence

- **Motion in an image** sequence refers to the change in position of objects or pixels over time across consecutive video frames. It occurs when an object moves, the camera moves, or both.
- In computer vision, motion is analyzed by **comparing two or more successive frames** to estimate how and where pixels have moved, which helps in tasks such as object tracking, activity recognition, and video surveillance.

Motion in an Image Sequence

For Example: If a person walks across a video, their pixel locations change from frame to frame — this change represents motion.

-Key causes of motion:

- Object movement
- Camera movement
- Scene depth variation
- Lighting changes

Often uses:

- Object tracking
- Optical flow estimation
- Human action recognition
- Video compression
- Autonomous driving

Motion Estimation

Finding how much and in which direction objects move between frames.

It estimates:

- Horizontal movement (x-direction)
- Vertical movement (y-direction)

A pixel moves:

Frame 1: (x, y)

Frame 2: (x+2, y+1)

*Motion estimation finds a **motion vector**:*

$$\vec{v} = \begin{pmatrix} dx \\ dy \end{pmatrix}$$

Types of Motion Estimation

- | 1. Pixel-based Motion Estimation | 2. Block-based Motion Estimation | 3. Feature-based Motion Estimation |
|--|--|---|
| <ul style="list-style-type: none">• Tracks intensity change of each pixel• Used in optical flow• Very accurate but computationally expensive | <ul style="list-style-type: none">• Image divided into blocks (e.g., 16×16)• Each block searched in next frame• Widely used in video compression (H.264, HEVC) | <ul style="list-style-type: none">• Detects keypoints (corners, edges)• Tracks features across frames• Used in object tracking and SLAM |

Mathematical Idea

*Assumption of **brightness constancy**:*

$$I(x, y, t) = I(x + dx, y + dy, t + 1)$$

- **Optical flow equation:**

$$I_x u + I_y v + I_t = 0$$

Component	Definition	Mathematical Expression
Horizontal Velocity (u)	Change in x over time	$u = \frac{dx}{dt}$
Vertical Velocity (v)	Change in y over time	$v = \frac{dy}{dt}$
Spatial Gradient (I_x, I_y)	Change in brightness across space	$I_x = \frac{\partial I}{\partial x}, \quad I_y = \frac{\partial I}{\partial y}$
Temporal Gradient (I_t)	Change in brightness across time	$I_t = \frac{\partial I}{\partial t}$

<i>Method</i>	<i>Description</i>
<i>Frame Differencing</i>	Simple subtraction between frames
<i>Optical Flow</i>	Pixel-level motion estimation
<i>Block Matching</i>	Motion per block
<i>Lucas–Kanade</i>	Local optical flow
<i>Horn–Schunck</i>	Global optical flow
<i>KLT Tracker</i>	Feature-based tracking
<i>Deep Learning</i>	CNN + FlowNet, RAFT

Optical Flow

The apparent motion of pixels between two consecutive frames.

-Simply: Optical flow tells how each pixel moves.

Optical flow detects that rightward movement:

*-When car is at left side (Frame-1)
and slightly move right (Frame-2)*

Brightness constancy

Pixel intensity does not change:

-Same pixel, just movement

$$I(x, y, t) = I(x + dx, y + dy, t + 1)$$

Optical Flow Intuition

Imagine: You watch two video frames quickly

Your eyes can tell what moved

Optical flow tries to do the same mathematically.

u : Horizontal Velocity (*the rate of change along the x – axis*).

v : Vertical Velocity (*the rate of change along the y – axis*).

Classic Optical Flow Methods:

- Lucas–Kanade Method (*Often applied method*)
- Horn–Schunck Method

Key idea: Instead of using one pixel, use a small window around the pixel. Because one pixel alone is not enough to estimate motion.

3×3 or 5×5 window

Lucas–Kanade assumes:

- motion is same inside a small patch
- pixels in patch move together.

Procedure

- I. Take a small window around pixel
- II. Compare window in next frame
- III. Find displacement that best matches

Feature Tracking Basics:

- Instead of tracking every pixel, we track.

Such as:

- I. Corners
- II. strong edges

Famous feature detector:

- Harris Corner Detector

Corners are best because:

- I. flat area → no information
- II. edge → ambiguous motion
- III. corner → unique motion

Motion Estimation and Optical Flow

- Motion in image sequences
- Motion estimation concept
- Optical flow intuition
- Lucas–Kanade optical flow
- Feature tracking basics

1 Motion in Image Sequences

- Motion is the **change of object position between consecutive frames** in a video.
 - Pixels move as objects move.
-

2 Motion Estimation Concept

- Motion estimation **finds how much and in which direction objects move** between frames.
 - Represented as **motion vectors** (dx, dy).
-

▲ 3 Optical Flow Intuition

- Optical flow tells **how each pixel moves between frames**.
- It's like tracking **pixel arrows showing direction and speed**.

▲ 4 Lucas–Kanade Optical Flow

- Estimates optical flow **using a small patch of pixels** instead of single pixels.
 - Assumes **all pixels in the patch move together**.
-

5 Feature Tracking Basics

- Track only **good features (corners or textured points)**, not every pixel.
- Good features are stable and easy to follow across frames.

- To analyze the movement of this pixel, we calculate the **displacement vector**, often referred to in computer vision as the **optical flow**.

A pixel moves from position

$(x, y) = (10, 15)$ in frame 1 to $(x, y) = (13, 18)$ in frame 2.

Find the motion vector (dx, dy) .

Find the magnitude of motion.

$$dx = 13 - 10 = 3 \quad dy = 18 - 15 = 3$$

$$\textit{Motion vector} = (3, 3)$$

$$\textit{Magnitude} = \sqrt{dx^2 + dy^2}$$

$$= \sqrt{3^2 + 3^2} = \sqrt{18} \approx 4.24$$